

Beta Clam Press

How to change a Rocker Switch

Replacement/Removal of Rocker Switch

N.B. Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply

1. Remove six screws from Rear Cover (pic 1)
2. Remove Rear Cover from Instrument Cover
3. Remove wires connected to Rocker Switch (pic 2), taking note of the connections for future reference when reinstalling new Rocker Switch
4. Remove the Rocker Switch (pic 3) by pushing out from Instrument Cover

Re-installation of replacement Rocker Switch

1. Installation is a reversal of removal

