

Mug Press

How to change a Micro Switch

Replacement/Removal of Micro Switch

- N.B.** Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply
1. Switch off machine and disconnect from power supply
 2. Remove rear Cover of Press by unscrewing the seven retaining screws (pic 1)
 3. Disconnect wiring to Micro Switch, taking note of the position of all connections for future reference when reinstalling (pic 2 arrow-a)
 4. Unscrew two nuts (pic 2 arrow-b) holding the Micro Switch to Bracket and remove switch from rear of Press

Re-installation of replacement Micro Switch

1. Installation is a reversal of removal

