

## Delta Cap Press

### How to change a Timer Unit

#### Replacement/Removal of Timer Unit

- N.B.** Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply
1. Remove Rear Cover Plate and 8 screws (pic 1)
  2. Remove Timer Unit by pulling upward from Socket (pic 2) leaving Socket attached to Base Plate (pic 2 inset)

#### Re-installation of replacement Timer Unit

1. Installation is a reversal of removal

