

Delta Junior Press

Symptoms

Test Procedure

Probable Cause and Fix

Heat Press going over set temperature

1. Faulty Thermo Rheostat

Heat Plate not heating

Red Lamp not illuminating

1. Check power supply and Fuse
2. Faulty Fuse Holder/Switch
3. Faulty wiring or Connector
4. Faulty Thermo Rheostat

Open circuit on Heat Element

1. Faulty wiring or Connector
2. Faulty Heat Element

When Pressing Lever is raised to the up position (it keeps falling down)

1. Broken or damaged Return Springs