

Studio Clam 28-38 Press

How to change a Magnetic Switch

Replacement/Removal of a Magnetic Switch

- N.B.** Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply
1. Remove Rear Cover by unscrewing 8 retaining screws (pic 1)
 2. Remove screws securing Magnetic Switch (pic 2)
 3. Remove Magnetic Switch Wires from main Control Unit using a screwdriver (pic 3), taking note of their position for future reference when reinstalling
 4. Pull wires out of Arm Assembly

Re-installation of replacement Magnetic Switch

1. Installation is a reversal of removal

