

Studio Clam Press

How to change a Solid State Relay

Replacement/Removal of Probe

N.B. Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply

1. Remove six screws from Rear Cover (pic 1)
2. Disconnect all wires going to Solid State Relay, taking note of the connections for future reference when reinstalling (pic 2)
3. Remove securing screws on Sold State Relay

Re-installation of replacement Solid State Relay

1. Installation is a reversal of removal
- N.B.** Heat Sink Compound should be applied to base of Solid State Relay before fitting

