

## Studio Mug Heat Press

### How to change a Controller

#### Replacement/Removal of a Controller

**N.B.** Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply

1. Remove Back Cover and 4 screws (pic 1)
2. Remove covers from wires by turning in an anticlockwise direction (pic 2)
3. Untwist wires from each other (pic 3), taking note of their position for future reference when reinstalling
4. Remove Controller from Cast Body (pic 4)
5. Cut cable ties holding cables together (pic 5 arrow-a)
6. Remove Micro Switch connector from Controller by pulling Plug upwards (pic 5 arrow-b)
7. Remove Probe wires using a screwdriver, taking note of their position for future reference when reinstalling (pic 5 arrow-c)
8. Pull wires out from Cast Body hole (pic 6)

#### Re-installation of replacement Controller

1. Installation is a reversal of removal

