

Delta Junior Heat Press

How to change an On/Off Switch

Replacement/Removal of On/Off Switch

N.B. Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply

1. Remove Instrument cover by bunscrewing two securing screws (pics 1 & inset reverse view)
2. Remove nut securing Switch to Instrument Cover (pic 1 arrow-a)
3. Pull Switch out from Instrument Cover
4. Disconnect wires from Switch (pic 2), taking note of the position of all connections for future reference when reinstalling

Re-installation of replacement On/Off Switch

1. Installation is a reversal of removal

